



Tambour Doors

Bar Lock Installation.

With our ongoing R & D, we have made it easier to install Bar Lock.

In the past, we supplied a mounted stop which was screwed into the side tracks.

Now we router a hole in each side track which is easier to install and looks great.

The procedure is as follows:-

The tambour Door will be supplied with the bars attached to the aluminium backplate and the lock is screwed in place.

- 1 Position the side tracks and mark the hole position on the cabinet carcass for each bar.
- 2 Drill a 12 mm diameter hole, 10 mm deep, in each side of the cabinet.
- 3 Remove the bars and saddles from the aluminium backplate and keep the position /order of fitting.
- 4 Install the tambour door as per the normal instructions.
- 5 Thread the saddles onto the bar.
- 6 Hook the bar under the lock and align the pin to the hole in the bar.
- 7 Screw the saddle back onto the backplate.
- 8 Fit the rosette over the lock barrel and press firmly in place.
- 9 Check if the lock works as intended.