



# Tambour Doors

## Mortice Lock Installation



The tambour door has been pre-drilled for the mortice lock and the handle is in 2 pieces.

Screw-fix the handles through the Tambour Door into the aluminium Back-plate.

Fit the mortice lock.

Test the lock operation with the key.

Place the escutcheon plate on the benchtop in the correct position to align with the lock tongues.

When final position is established, mark the outline of the plate.

Rout the benchtop outline to the correct depth then screw-fix the plate in position.

Test the lock connection to the escutcheon plate.